


INSTALLATION AND SERVICE MANUAL


LIGMAN
NORTH AMERICA

For Installation of Arizona Wall Light Dia 6.3" LED.
Model. UAR-30994


Product drawing (dimensions)




MOUNTING DETAIL




SUITABLE FOR WET LOCATIONS



1




2




3

Center the Back Plate over the J Box and Secure the back plate to the wall




Ensure watertight seal using UL approved silicone based sealant.

4



Connect Power and Ground Wire.

5



Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,**Check that the supply voltage is the same as the installed ballast voltage.

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UAR-30994 09/04/24 REV.1
1/1

FM-TS-13-1/13-05-2563/Rev.6