


INSTALLATION AND SERVICE MANUAL



For installation of Cinati wall washer LED.
Model. UCI-30121 and UCI-30131.



Product drawing (dimensions)

SUITABLE FOR WET LOCATIONS




UCI -30121

UCI-30131 (LENS TYPE)





MOUNTING DETAIL




NOTE

Mounts over
a Junction box.


1





Position the Back Plate
over the J Box and Secure
the back plate to the wall



Ensure watertight seal using
UL approved silicone based sealant.



Connect Power
and Ground Wire.



Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST**,Check that the supply voltage Is the same as the Installed ballast voltage.

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UCI-30121 01/04/24 REV.2
1/1

FM-TS-13-1/13-05-2563/Rev.6