


# INSTALLATION AND SERVICE MANUAL

**LIGMAN**  
NORTH AMERICA


For Installation of KWH 1 (For Threaded Knuckle Mount and Includes)  
Model. UKWH-30001

## Product drawing (dimensions)


SUITABLE FOR WET LOCATIONS




UKWH-30001




1



2




Connect Power  
and Ground Wire




3


4



5




6




ADJUST

7



8



## Notice to installer :

- 1. WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2. This fixture has a VOLTAGE SPECIFIC BALLAST, Check that the supply voltage is the same as the installed ballast voltage.**

**Ligman Lighting USA**

7144 NE Progress Court, Hillsboro  
Oregon, 97124, USA  
Tel : 503 645 0500 | Fax : 503 645 8100